




Daily Cleaning



The following cleaning process needs to be completed daily

<p>Open the door and insert internal plastic key to turn on machine</p>	
<p>Press the service button (13) located on the back of the door (menu will appear at the front)</p>	
<p>Push button 4 = Clean</p>	
<p>Place a cup under the hose exits and run through cycles 1, 2, 3 and 4 to rinse the pipes</p>	

Weekly Cleaning


The following cleaning process needs to be completed once a week

1. Power off the machine
2. Carefully remove the canisters, the mixing bowls, outlet pipes and drip tray by following these steps:

<p>Remove and empty the drip tray (a), remove the upper grill cover and clean all components thoroughly</p>	
<p>Remove the mixer bowls by turning the orange lever clockwise (d) and removing the hose from the outlet (e). Wash complete assembly with lukewarm water.</p> <p>REMEMBER to always unclip the outlet pipes from the hose exits (e), never pull them out of the connected mixing bowl (d).</p>	

Remove the product containers, ensuring you close the outlets prior (c). These are coloured RED or ORANGE

REMEMBER product cannisters should never be disassembled. As long as the product is topped up often and not kept in the machine for over 1 week, cannisters can remain complete.



Clean the interior of the machine with a damp cloth.

Remove any excess ingredients from the machine components and wash under warm water and dry thoroughly.



Mount all the cleaned components to the original positions

ENSURE all canisters are located back properly otherwise the product will not flow

LEAVE mixing bowls damp to ensure seals do not split on mixer motor

Open the canister hatches and perform daily clean

3. Run the cleaning process by following these steps:

<p>Open the door and insert internal plastic key to turn on machine</p>	
<p>Press the service button (13) located on the back of the door (menu will appear at the front)</p>	
<p>Push button 4 = Clean</p>	